



**Newer Caterpillar, Cummins & PACCAR
Engines are equipped with Crankcase Filters!
Crankcase Filters Should be Replaced at
Recommended Intervals**

**Failure to Replace Crankcase Filters may
result in High Crankcase Pressures, Activation
of the Check Engine Light, Poor Performance
and Engine Shutdown.**

Caterpillar	INTERVAL*
C13 & C15	90,000 miles
Cummins	INTERVAL*
ISB ISC	60,000 miles
ISM	150,000 miles
ISX	120,000 miles
PACCAR	INTERVAL*
PX6 PX8	60,000 miles



* Recommended crankcase filter replacement intervals may be adjusted based on engine blowby.